

How to remove Tape Residue & Adhesives

Spray On**Let Soak****Scrub****Wipe Dry**

- 1 Spray the tape residue or adhesive with **SafeSolv**
- 2 Let soak for 1-5 minutes
- 3 Scrub with the **Aero Scrubber** or soft brush
- 4 Wipe with towel
- 5 Repeat until the tape residue or adhesive is completely removed
- 6 Clean the area with **Wash Wax ALL** (Blue).

NOTE:

- **SafeSolv** is a non-toxic biodegradable way to remove tape residue and adhesives.

