

How to use the Wash Wax Mop

- 1 Spray the *Wet side* with 10-12 spray pumps of **Wash Wax ALL**. (This is to prime a new dry pad)
- 2 Spray **Wash Wax ALL** on the area to be cleaned. We recommend about one spray pump per square foot.
- 3 Wipe the area with the *Wet side* of the mop.
- 4 Flip the Mop over to the *Dry side* and dry the area before the Wash Wax ALL dries on its own.
- 5 In order to apply **Wash Wax ALL** to hard to reach areas, rotate the sprayer nozzle to stream and spray **Wash Wax ALL** on to the surface OR spray directly on to the *Wet side* of the Mop and then wipe the area to be cleaned.
- 6 Once the *Wet side* pad gets dirty, replace it with the *Dry side* pad and put a fresh clean pad on the *Dry side*. This will allow you to get the most use out of each pad.



Helpful Tips:

- **The *Wet side* should only be damp.** Do not over-saturate the *Wet side* or you may begin to see streaking. If the *Wet side* gets over-saturated, stop spraying Wash Wax ALL on to the *Wet side* and continue cleaning new areas until the *Wet side* becomes only damp. The most common mistake our customers make is using too much Wash Wax ALL.
- **Top Down-** clean the high areas first to prevent spray mist from landing on clean areas.
- **Stay up-wind-** keep the dirty areas downwind of your cleaning spray.
- **Do the dirtiest** painted areas last. Then put two (2) fresh and clean Mop Pads on and clean the windows.
- **Keep in mind** when it's hot and dry the surface will dry faster, so you will do smaller areas at a time. When it is cold and damp it takes longer to dry so you will do larger areas.
- **Do not place the Mop on the ground.** The pads may pick up contaminants that can scratch the surface.
- **Machine wash** the microfiber pads with laundry detergent and machine dry. Do not use fabric softener, as this will make the microfiber less absorbent. To avoid lint, do not wash microfiber with cotton products.
- **Do not wash** mop pads or towels with shop towels that may contain metal shavings, wood shavings, or other sharp contaminants. Avoid laundry services that wash towels for machine shops.
- **Inspect** mop pads and towels for contaminants that may scratch after washing and before each use.
- **Store** mop pads and towels in a dirt free container or bag.
- **Tighten the wing nut** to prevent the Mop from pivoting too easily. We recommend that the wing nut be tight enough to provide some resistance when you pivot the mop by hand.
- **We do not recommend** using the Mop with an extension pole longer than 12 feet.
- **There is a locking pin for the swivel.** We recommend that you leave it locked when you first start using the Mop. Once you are comfortable using the Mop, take out the pin and store it in the hole below the lock hole. At first it may seem difficult to control, but once you get the feel of it, you may want to leave it unlocked. The unlocked position gives you greater flexibility and maneuverability using the mop. Whether you leave the lock in or take it out is your personal preference.

Do Not use the Mop from a ladder!

WARNING: The mop was developed to eliminate the need for a ladder. **DO NOT USE THE WASH WAX MOP FROM A LADDER** as you will not be able to use the mop and hold on to the ladder at the same time, thus increasing your chances of falling.